

# Oase Preformed Ponds

*Easy step-by-step installation!*



## 1. Location

The ideal pond location is away from deciduous trees and conifers and has approximately 4 - 6 hours of sunlight daily.



## 2. Tools

For installation you require: Spade, shovel, filler sand, level, yardstick, and a garden hose with water connection.



## 3. Marking

First, position the preformed pond in the desired location, then mark the contours with sand.



## 4. Deep zones

The different deep zones are also marked with sand incrementally.



## 5. Excavation

Generously dig out the specific zones of the garden pond.



## 6. First test

Then insert the preformed pond to see how it fits.



## 7. Fill-in

Adjust the different excavated levels with filler sand to compensate unevenness.



## 8. Levelling

The floor and the pool are levelled out in length and width. Then the pool is filled with water to approximately 1/3.



## 9. Backfilling

All around the perimeter, wet sand is backfilled under the edge of the preformed pond to fill any cavities.



## 10. Filling and compensating

In the final step, the area around the preformed pond is adapted to the preformed pond with sand, soil, gravel, etc.



## 11. Edge area décor

Now you can start planting and designing the pond. Ensure that you completely fill the perimeter bank zone with gravel.



## That's it!

In just a short time, your own pond is ready!